

88–200 Removal and installation, disassembly and assembly of front bumper

Removal

- 1 Remove air grille under bumper.
- 2 Unscrew bumper mounting bracket on cross member front.
- 3 Remove bumper with mounting bracket.

Disassembly

- 4 Slightly unbend fastening tongue for protective rail.
- 5 Pull off protective rail left and right.
- 6 Unscrew mounting bracket from reinforcement.
- 7 Unscrew cover molding on bumper joint left and right, pull outwards and remove.
- 8 Unscrew bumper top left and right.
- 9 Unscrew reinforcement and separate from bumper shell center.

Assembly

- 10 For assembly proceed vice versa.

Installation

- 11 For installation proceed vice versa.

Note: Align bumper in such a manner that the lateral distance from center to fender rim is the same on both sides.