Special tool


Knurled socket wrench SW 8

116 589 03 09 00


Removal

- 1 Remove center console (68-200).
- 2 Remove glovebox (68-140).
- 3 Remove combination instrument (54-310).
- 4 Remove reveal molding left and right on windshield (68--405).
- 5 Remove cover left and right under instrument panel (68–150).
- 6 Unscrew knob on pull rod of pedal parking brake and remove rubber disc.
- 7 Pull-off operating knob of rotary light switch and unscrew nut (SW 24) behind.
- 8 Push-out rosette on steering lock and remove.
- 9 Remove air hoses between center air duct and lateral ring nozzles.

10 Unscrew screws (1) on instrument panel left.




11 Reach through cutout for combination instrument and unscrew nut (2).



2 Nut (SW 8) left

12 Reach through opening for glovebox and unscrew nut (3).





3 Nut (SW 8) right 7 Screws on instrument panel right

- 13 Also reach through cutout for glovebox and unscrew screw (4), leaving only a few final threads.
- 14 Disconnect regulating linkage (5) for summer air flap.
- 15 Disconnect connecting hose (6) between heater box and rosette on heater box.



- 6 Connecting hose
- 16 Unscrew screws (7) at right of instrument panel.
- 17 Pull off both plugs on switch of glovebox light.
- 18 With loudspeakers installed, disconnect connecting cable on plug connection.
- 19 Raise instrument panel front slightly, so that threaded studs at left and right will disengage.





- 20 Push righthand upper corner of instrument panel downwards with a plastic wedge.
- 21 Remove instrument panel at righthand end first.

Installation

- 22 Push instrument panel from the right into the lefthand corner on front wall pillar.
- 23 Push instrument panel forward so that defroster nozzles are correctly connected to heater box.
- 24 For further installation proceed vice versa.