

Removal

- 1 Unscrew screws (1) on ornamental molding (2).
- 2 Pull ornamental molding (2) on rear pillar out of clip on weather strip (4) toward the rear.
- 3 Unscrew screws (3) on weather strip (4) and remove weather strip (4).



Installation

- 4 Place moltopren ring on the plastic dowel for sealing and push into folded sheet–metal.
- 5 For further installation proceed vice versa.