



07.4—221 Replacing fuel hoses on ring line

Replace fuel hoses according to specified dimensions or according to removed fuel hoses. For assembly instructions refer to 07.4—220.

1st version



2nd version



3rd version

