


**Note**

---

**Attention!**

When working on breakerless transistorized ignition system, be sure to observe the following safety instructions:

- Persons with heart stimulators should not work on such ignition systems.



Information plate in engine compartment

1154-9352

- With the engine running or at starting speed, do not touch, pull off etc. components of ignition system, ignition cable, ignition coil, spark plug connector.
- Perform assembly jobs on ignition system only with engine stopped and ignition switched off.

Also connect and disconnect test instruments only with engine stopped and ignition switched off (15–531).

- Do not install adapters or transmitters, e. g. for stroboscope, into ignition cable, e. g. cylinder 1, which are metallically bright.