


Models 108 111 113 114 115

Oil type

Hypoid transmission oil SAE 90

refer to „Specifications for Service Products“ page 235



40 Plug

- Unscrew plug on the steering housing. With the steering in central position, the **oil level** should reach **to the lower edge** of the threaded plug hole. If necessary top up with hypoid oil SAE 90.