


All models

**Tightening torque**

Nm (kpm)

Locking bolts for attaching steering box to frame

70–80 (7–8)



2 Fixing bolts for steering box

- Check the three hexagon and/or locking bolts for tight fit and retighten if necessary.

**Note**

To check the torque of locking bolts they must not be loosened.

If the tightening torque is below the rated torque the locking bolts must be retightened accordingly.