



## **Combination Switch**

- 1 Low beam (turn light switch clockwise two notches)
- 2 High beam (turn light switch clockwise two notches)
- 3 Headlight flasher (high beam available independent of light switch position)
- 4 Turn signals, right
- 5 Turn signals, left

To operate the turn signals, move the combination switch past the point of resistance (up or down). The switch is automatically cancelled when the steering wheel is turned by a large enough angle.

To signal minor directional changes of the vehicle, such as changing lanes on a highway, move combination switch to the point of resistance only and hold it there.

6 Control for windshield washer system

When the washer system is switched on, the wipers also operate

- 7 Windshield wiper control
  - 0 Windshield wiper switched off
  - I Intermittent wiping
  - II Normal wiper speed
  - III High wiper speed

## Hints:

If one of the turn signals fails, the turn signal indicator system flashes and sounds at a faster sequence than under normal operating conditions. Fog lights will only operate together with low beam headlights. Fog lights are turned off automatically when light switch is returned to off-position.