


1 Adjust adjusting nut (1) of cable control envelope in such a manner that the wire strand rests against regulation with the lowest possible play.

Attention!


On carburetor engines, adjust idle speed at operating temperature.

Model 107




154 - 9219/1

Models 114.060/073, 116.020



107-1017

Models 116.032/033



154 - 8964/1